



DSP BOARD
R3DI
V2.2

FB5

5

J5

J8
USB

J3

R18
R17

R32
R31

U6

R12
R11
R10
R9
R8
R7
R6
R5
R4
R3
R2
R1

C15

C43
C42
C41
C40
C39
C38
C37
C36
C35
C34
C33
C32
C31

R16
R15
R14
R13
R12
R11
R10
R9
R8
R7
R6
R5
R4
R3
R2
R1

C25
C24
C23
C22
C21
C20
C19
C18
C17
C16
C15
C14
C13
C12
C11
C10
C9
C8
C7
C6
C5
C4
C3
C2
C1

Q3

Q4

Q1
Q2

R8
R7
R6
R5
R4
R3
R2
R1

D3

PM2

PM1

U3

U1

X12

BAT1

J1

J2

J3

J4

J5

J6

1

51

76

TP1

+

+

+

+

+

RA12

RA5

RA4

RA3

RA2

RA1

RA6

RA7

RA8

RA9

RA10

RA11

RA6

RA7

RA8

RA9

RA10

RA6

RA7

RA8

RA9

RA10